

# Refill Instructions - Brother LC1000/LC51

## Printers

Brother MFC : 240, 440, 660, 665, 845, 850, 3360, 5460, 5860  
DCP : 130, 330, 540, 750  
FAX : 1360, 1860, 1960, 2480, 2580

## Items Required

Original Brother LC1000 Cartridge, Syringe & Filling Tube, Knife, Ink 10ml for the colours or 20ml for the black, Tape



## Instructions

Note : The cartridges for each colour have the same basic design so the instructions are the same for all LC970

1. Lay down some newspaper to help prevent any mess
2. Cut around the edge of the cartridge with a sharp knife. (fig.1)
3. Grab cartridge casing at ink nozzle end and pull apart This may take a bit of force the 1st time. (fig.2)
4. Attach the filling tube to the syringe and then fill with 10ml of the required colour.
5. Pierce the top part of the cartridge, as shown in (fig.3), and **SLOWLY** inject the ink into the cartridge.
6. Once the cartridge is full then seal the filling hole with a bit of tape.
7. Reattach the casing and seal in place using another bit of tape. (fig.4)
8. Place the cartridge back in the machine and run a couple of head cleans to ensure the best results.

For more info go to [help.jrinkjet.co.uk](http://help.jrinkjet.co.uk)

